
C23511BN
Push button waste 1¼'', brushed nickel finish


CRESTIAL
Wasser Musik

FEATURES

- fully brass body
- G1¼" outlet connection
- universal fitting (for basins with / without overflow)
- press down to close (fill basin) or press down again to open (drain water)
- brushed nickel finish for parts above basin







While we endeavor to provide accurate information, it may be subjected to errors and omissions. We reserve the right to update any information without prior notice.